

ANALOG MODULE



PRODUCT DESCRIPTION

M2.ANM.15 analog module has 4 input channels with maximal 16-bit resolution (12 bit with factory default calibration) and 4 output channels with 12-bit resolution.

Input section of module is used for accepting and processing of all standard analog signals (current, voltage, and RTD). Simultaneously, every channel can accept a different type of analog signal.

Output section of the module is used for setting up analog values (current and voltage). Simultaneously, every channel can generate a different type of analog signal.

Module is compliant with: EN 61131-1:2003, EN 61131-2:2003

TECHNICAL DATA


ANALOG INPUT CHARACTERISTICS	
Number of inputs	4
Type of inputs	Jumper selectable per channel: - current (0-20 mA) - voltage (0-10 V) - RTD (Pt100 -200 to 850 °C)
Resolution	16 bit (12 bit with factory default calibration)
Input impedance	- current – 100 Ω - voltage – 10 $k\Omega$
Maximum permanent overvoltage	±20 V
Galvanic isolation	Yes, optocoupled, 2.5 kV
ANALOG OUTPUT CHARACTERISTICS	
Number of outputs	4
Output type	Jumper selectable - current (0-20 mA) - voltage (0-5 V) - voltage (0-10 V)
Resolution	12 bit
Settling time for full range swing	1 ms
Output load	current $\leq 500 \Omega$, voltage $\geq 1 k\Omega$
Galvanic isolation	Yes, optocoupled, 2.5 kV
ADDITIONAL SPECIFICATIONS	
Operating temperature	0 +55 °C
Storage temperature	-30 +80 °C
Operating humidity	Max 95% r.H., no condensation
Protection degree	IP20
Dimensions	108x86x27 mm
Weight	120 g
EBUS consumption	100 mA
External power supply	24 VDC/150 mA




PRODUCT FEATURES


- 4 analog inputs and 4 analog outputs
- Inputs operate in self-scan mode
- Monotonicity with no missing codes is guaranteed
- Calibration is performed during production. Inputs can be recalibrated using PC based application
- Configuration of input / output type is performed by jumpers


WIRING AND RESOURCES





DIMENSIONS AND MOUNTING





SAFETY NOTES



- application, especially in aircraft or in any other airborne means of transport.
- It may only be installed by suitably trained personnel.
- Any legal regulations or regulations issued by authorities must be observed during assembly.
- The device is not allowed to be used outside the specified field of The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by
 - The device contains electrical and electronic components and is not allowed to be disposed of as household refuse. All locally valid regulations and requirements must be observed.